



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'
1	<a href="#">04025</a>	Hair Guard Screw	2
2		Hair Guard	
2a	<a href="#">15248</a>	Hair Guard - Edjer (UL)	1
2b	<a href="#">15246</a>	Hair Guard - T-Edjer (UL)	1
2c	<a href="#">15247</a>	Hair Guard - (CSA)	1
3		Front Cover Screw	
3a	<a href="#">15023</a>	Front Cover Screw	1
3b	<a href="#">04933</a>	Black Front Cover Screw	1
4		Rear Cover Screw	
4a	<a href="#">04023</a>	Rear Cover Screw	1
4b	<a href="#">04653</a>	Black Rear Cover Screw	1
5		Upper Housing	
5a	<a href="#">15916</a>	Upper Housing	1
5b	<a href="#">15914</a>	Black Upper Housing	1
5c	<a href="#">15569</a>	Upper Housing - Experience	1
6		Armature Assembly	
6a	<a href="#">S15511</a>	Armature Assembly - 2 wire (includes Tension Spring Assembly, Tension Spring Pad, and Tension Spring Screw.	1
6b	<a href="#">S15537</a>	Armature Assembly - 3 wire (includes Tension Spring Assembly, Tension Spring Pad, and Tension Spring Screw.)	1
7		Field Core Assembly	
7a	<a href="#">S15502</a>	Field Core Assembly - 2 wire	1
7b	<a href="#">S15544</a>	Field Core Assembly - 3 wire	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
8		Cord	
8a	<a href="#">15771</a>	Cord Set - 2 wire	1
8b	<a href="#">15536</a>	Cord Set - 3 wire	1
9	<a href="#">65842</a>	Hanger Hook	1
10		Lower Housing	
10a	<a href="#">15911</a>	Lower Housing	1
10b	<a href="#">15909</a>	Black Lower Housing	1
11	<a href="#">15029</a>	Terminal Screw	2
12	<a href="#">15014</a>	Switch Contact Spring	1
13	<a href="#">S15867</a>	Switch Button	1
14	<a href="#">26899</a>	Lower Blade Screw	2
15	<a href="#">15024</a>	Field Screw	2
16	<a href="#">15013</a>	Cover Screw Pad	1
17	<a href="#">15071</a>	Cover Screw Pad Screw	1
18	<a href="#">15046</a>	Field Screw	1
19	<a href="#">04229</a>	Terminal Screw (3 wire only)	1
20	<a href="#">01296</a>	Lock Washer (3 wire only)	1

**IMPORTANT INFORMATION**

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.