


D-6

CONNECTOR



NOTE: NUMBERS SHOWN ON DRAWING ARE INDEX NUMBERS. NUMBER, PARTS BY CORRECT NUMBER.

SEE FRAME B-8, PAGE 21, FOR BLADE SET & TENSION SPRING CHART, BLADE ADJUSTMENT SPECIFICATIONS AND BUSHING & RIVET SET INFORMATION.

