andis®

MODEL MBA CLIPPER
120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Upper Housing Assembly	
1a	65301	Upper Housing Assy. "Select Cut" Black	1
1b	65302	Upper Housing Assy. "Tack Mate" Black	1
1c	65063	Upper Housing Assy, "Exp." Met. Blk	
2	65138	Lower Housing	1
3	23821	Motor Assy	1
4	65842	Hanger Hook	1
5	65346	Blade Drive Assy	1
6	65308	Tension Spring Assy	
7	65309	Motor Frame Assy	1
8	65808	Switch Actuator	1
9	65311	Speed Control Assy	1
10		Cord	
10a	63999	Cord (8')	1
10b	65314	Cord (16')	1
11	65816	Blade Bracket	1
12	65312	Blade Mounting Screws	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.