andis®

OUTLINER TRIMMER
T-OUTLINER TRIMMER
120 VOLT





ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	04025	Hair Guard Screw	2
2		Hair Guard	
2a	04071	Outliner (CSA)	1
2b	04203	Outliner (UL)	1
2c	04065	T-Outliner (UL)	1
3		Cover Screw	
3a	04023	Brite zinc	2
3b	04653	Black	2
4		Upper Cover Assembly	
4a	08911	Grey Assy, Ergo Button (UL)(1, 2b)	1
4b	08912	Grey Assy, Ergo Button (CSA)(1,2a)	1
4c	08913	Black Assy, Ergo Button (CSA)(1,2a)	1
4d	08914	Grey Assy, Ergo Button (UL)(1,2c)	1
5	04229	Terminal Screw (CSA 3-Wire)	1
6	01296	Lockwasher (CSA 3-Wire)	1
7	01403	Switch Pad Screw	1
8	05032	Field Screw	1
9		Motor Assembly	
9a	S04515	2 Wire-UL (10,22,23)	1
9b	S04527	3 Wire-CSA (22,23)	1
10	S04508	Field Assembly	1
11		Cord Set	
11a	04624	2 Wire-UL	1
11b	04617	3-Wire-CSA	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
12	65842	Hanger Hook	1
13		Lower Case	
13a	06527	Grey	1
13b	06526	Black	1
14	26899	Lower Blade Screw	2
15	04116	Fiber T-Guide	1
16	15886	T-Guide Washer	1
17	04648	T-Guide Screw	2
18	04022	Field Screw	1
19	04108	Tension Spring Assembly	2
20	32527	New Style Tension Screw (no washer)	2
21	29752	Tension Spring Screw	2
22	04532	Armature Spring Assembly	1
23	03999	Armature Support Screw	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.