SCT CLIPPER/TRIMMER 120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Upper Housing	
1a	72022	Upper Housing - White	1
1b	72097	Upper Housing - Metallic Blue	1
1c	72121	Upper Housing - Fuscia	1
1d	72101	Upper Housing - Black	1
2		Lower Housing	
2a	72021	Lower Housing - White	1
2b	72096	Lower Housing - Metallic Blue	1
2c	72118	Lower Housing - Fuscia	1
2d	72086	Lower Housing - Black	1
3	-	-	-
4	72017	Switch Button	1
5	72048	Motor/Cam Assembly	1
6	32580	Housing Screws	3
7	72034	Motor Mounting Screw	1
8	72023	Cord	1
9	72108	Tab	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.

Rev-B 6-11-07